

## GEN 4 INTAKE COVER INSTALL

- Start by removing the oem cover. Simply pull up and towards the front of the motor. The rear is held in by rubber mounts only. Once that is off unbolt the 2 bolts that hold on the rubber mount in the rear of the intake and the 1 bolt that the front of the intake sat on.
- Next, install the provided threaded bungs, the taller one goes in the front.





- NOW THE CONVER WILL BOLT RIGHT ON

