

GEN 3 INTAKE COVER INSTALL

- Start by removing the oem cover. There is one center 8mm bolt, remove that and lift up and pull towards the front of the engine. The rear is held in by rubber mounts only. Once that is off unbolt the 2 bolts that hold on the rubber mount in the rear of the intake.
- Next determine if your intake has an EVAP solenoid installed and if it is still needed. (CIRCLED IN RED)



- If you do need the EVAP solenoid, you will need to purchase the threaded spacers to clear the solenoid. (you will receive 3 of the same size spacers)



- If you do not need a EVAP solenoid, we sell a Delete plug if need (pictured below)





- After that just simply need to sit the gen 3 cover on the intake and bolt down with the supplied metric hardware.